



- | | |
|---------------------------------------|-----------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiuni de montaj |
| TR Montaj talimati | RU Инструкция по монтажу |

1387.30 Couchtisch Vista 3






**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**



Name • Nom • Nome • Naam
Nazwa • Jméno • Назов • Név
Dепутатре • İsim • Название









Nr • No. • N° • Номер • С • Sz

Typ • Type • Тип • Típus • Típo
Тип





- 2x ①
- 2x ②
- 1x ③
- 1x ④
- 2x ⑤



A**B**

C



D

